

PREP SHEET

Before our expert installation team arrives at your dealership, please do the following for all vehicles we'll be installing Brake Plus into:

MODEL	INSTRUCTIONS	MODEL	INSTRUCTIONS
Acadia	Open trunk	Sierra (2019)	Open rear driver-side door
Canyon	Don't open	Terrain	Open trunk
Sierra	Don't open	Yukon	Open trunk

ADDITIONAL INFORMATION:

We do NOT need the keys to be left *in* or *on* the vehicles.

QUESTIONS?

Contact our installation manager: cervantes@brake-plus.com
(602) 388-9233