

# PREP SHEET

Before our expert installation team arrives at your dealership, please do the following for all vehicles we'll be installing Brake Plus into:

MODEL	INSTRUCTIONS	MODEL	INSTRUCTIONS
<b>370</b>	Open trunk hatch	<b>Pathfinder</b>	Open trunk hatch
<b>Altima</b>	Open trunk	<b>Quest</b>	Open trunk hatch
<b>Armada</b>	Open trunk hatch	<b>Rogue</b>	Open trunk hatch
<b>Frontier</b>	Open rear passenger-side door	<b>Sentra</b>	Open trunk
<b>Kicks</b>	Open trunk	<b>Titan</b>	Open rear driver-side door
<b>Maxima</b>	Open rear driver-side door	<b>Versa</b>	Open trunk
<b>Murano</b>	Open trunk	<b>Versa Note</b>	Open trunk hatch
<b>NV</b>	Open rear door		

## ADDITIONAL INFORMATION:

We do NOT need the keys to be left *in* or *on* the vehicles.

## QUESTIONS?

Contact our installation manager: [cervantes@brake-plus.com](mailto:cervantes@brake-plus.com)

(602) 388-9233