

# PREP SHEET

Before our expert installation team arrives at your dealership, please do the following for all vehicles we'll be installing Brake Plus into:

MODEL	INSTRUCTIONS	MODEL	INSTRUCTIONS
Promaster	Open rear door	Ram	Don't open
Promaster City	Open rear door		

## ADDITIONAL INFORMATION:

We do NOT need the keys to be left *in* or *on* the vehicles.

## QUESTIONS?

Contact our installation manager: [cervantes@brake-plus.com](mailto:cervantes@brake-plus.com)

(602) 388-9233