

# PREP SHEET

Before our expert installation team arrives at your dealership, please do the following for all vehicles we'll be installing Brake Plus into:

MODEL	INSTRUCTIONS	MODEL	INSTRUCTIONS
<b>86</b>	Open hatch	<b>Prius C</b>	Open rear driver-side door
<b>4Runner</b>	Don't open	<b>Prius Prime</b>	Open hatch
<b>Avalon</b>	Open rear doors	<b>Prius V</b>	Open hatch
<b>C-HR</b>	Open hatch	<b>Rav4</b>	Open hatch
<b>Camry</b>	Open rear driver-side door	<b>Sequoia</b>	Don't open
<b>Corolla</b>	Open rear driver-side door	<b>Sienna</b>	Open hatch
<b>Corolla Hatchback</b>	Open hatch	<b>Tacoma</b>	Open rear driver-side door
<b>Highlander</b>	Open hatch	<b>Tundra</b>	Open rear driver-side door
<b>Land Cruiser</b>	Open hatch	<b>Venza</b>	Open hatch
<b>Mirai</b>	Open hatch	<b>Yaris</b>	Open hatch
<b>Prius</b>	Don't open	<b>Yaris IA</b>	Open rear driver-side door

## ADDITIONAL INFORMATION:

We do NOT need the keys to be left *in* or *on* the vehicles.

## QUESTIONS?

Contact our installation manager: [cervantes@brake-plus.com](mailto:cervantes@brake-plus.com)

(602) 388-9233